

# 08099300 MANUAL BATTERY DISCONNECT SWITCH ACCESSORIES

Keys • Handles • Chains • Caps



08099300



08099600



08099700



08099800



08099900



00603800



00603900



00902400



00902500



00902600



00227200



08089800



00902200



00902700



00903000

## Ordering Information

PART NUMBER	PACKAGING CONTENT	DESCRIPTION	MATERIAL	BATTERY SWITCHES APPLICATION
08099300	2 pcs.	Key	Metal	08098300
08099600	5 pcs.	Handle	Metal	08098600
08099700	10 pcs.	Key	Plastic	08098700-08098768-08098780
08099800	5 pcs.	Handle	Metal	08098800-08098900
08099900	10 pcs.	Key with rubber	Plastic	08098700-08098768-08098780-08099000-08099080
00603800	10 pcs.	Rubber protection cap	Grommet	08099500
00603900	10 pcs.	Rubber protection cap	Grommet	08098700-08098700-08099000
00902400	5 pcs.	Handle with protection cap	Metal	08098880-08098980
00902500	5 pcs.	Small chain	Metal	08098880-08098980
00902600	5 pcs.	Rubber protection cap	Grommet	08098880-08098980
00227200	2 pcs.	Stiff protection sheath	Plastic	08099170
08089800	5 pcs.	Key	Plastic	08080800
00902200	10 pcs.	Key	Plastic	08080300-08080380-08080400-08080480
00902700	5 pcs.	Rubber protection cap	Grommet	08080300-08080380-08080400-08080480
00903000	1 pcs.	Electrical resistance	Ceramic	08080100-08080400-08080480

# Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Littelfuse:

[24505](#) [82065](#) [08099700](#) [08099800](#) [08089800](#) [08099600](#) [08099300](#) [00603900](#) [08099900](#) [00902400](#) [00903000](#)  
[00902500](#) [00902600](#) [00902200](#) [00902700](#) [00227200](#)